



## Rider's Claw Assembly Instructions



Remove upper and lower torque screws from clutch/cable bracket.



Assemble Back Plate, Stand Offs (2), and 1/4-20 x 1 3/4" (2) Button Head Screws (Note pictures below to insure the button head screws rest inside counter bores and the stand offs are flush to flat side of the back plate).



Secure Back Plate to clutch/mirror bracket with Allen wrench



Assemble 10-32 x 1/2" Flat Head Screws into Rider's Claw



Secure Rider's Claw to Back Plate with Allen wrench.

## Suggested Stealth Auxiliary Cord Assembly



Plug right end angle into iPod



Use plastic ties (supplied) to tie auxiliary cable to electrical switch wire cable (left or right side). Push straight male end through fairing where handle bar exits. Turn front wheel far right and reach up under inner fairing and pull cord slack through.



Run cord across inside of inner fairing to right side.

Remove Torx screw from inner fairing (see red arrow).

Pull back inner fairing about 1/2 inch and retrieve cord.

Run cord up to radio jack between inner fairing and radio.

Press inner fairing against cord and replace Torx screw

Coil any excess cable slack and tie up behind inner fairing.



Approximately 1"-2" of cord is all that is seen

For a right side mount... follow instructions in [Blue](#)